




CHROMEBOOK


INSTRUCTIONS FOR SETTING UP YOUR BORROWED CHROMEBOOK THE FIRST TIME

Step 1. Please plug in the power cord and let it charge

Step 2. How to connect your Chromebook to Wi-Fi

1. Click on the time, it will be in one of the screen corners.
2. Click on this symbol .

Step 3. Turn on Wi-Fi.

1. Your Chromebook will automatically look for available networks and show them to you in a list.
2. Scroll through the list and find your network provider (ask your wifi provider for more information if you need help).
3. Select the Wi-Fi network .

Step 4 Connect to the District website

1. Go to www.d91.k12.id.us
2. Click on “Single sign-on” (under the large main screen picture)
3. Enter your student’s school username and password, most students know this information, if not please ask their teacher.